

Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

| | | | |
|---|-------|---------------------------------|-------|
| Importance of Maintenance | P. 36 | Drive Chain | P. 72 |
| Maintenance Schedule | P. 37 | Clutch | P. 76 |
| Maintenance Fundamentals | P. 41 | Throttle | P. 79 |
| Tool kit | P. 52 | Crankcase Breather | P. 80 |
| Removing & Installing Body Components | P. 53 | Other Adjustments | P. 81 |
| Seat | P. 53 | Headlight Aim | P. 81 |
| Side Cover | P. 54 | | |
| Battery | P. 55 | | |
| Spark Plug | P. 56 | | |
| Engine Oil | P. 58 | | |
| Brakes | P. 61 | | |
| Side Stand | P. 70 | | |