| Periodic Checks You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently. | | Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ⊇ P. 32 |
|--|---|--|
| Tires and wheels | Check the air pressure (2 P. 45), examine tread for wear and damage (2 P. 45), and check the rims and spokes for damage. | |
| Fluid levels | Check the engine oil level (\blacksquare P. 53), and brake fluid level (\blacksquare P. 63). | |
| Lights | Check that the headlight, brake light, taillight and turn signals are working properly. | |
| Controls | Check the freeplay of the clutch lever (⇒ P. 73) and throttle grip (⇒ P. 76). | |
| Drive chain | Check the slack (➡ P. 67), adjust the slack (➡ P. 68), and lubricate (➡ P. 44) as needed. | |
| Fuses | Check that you have a full supply of spare fuses. | |
| Nuts & bolts | Check the major nuts and bolts, and tighten as needed. | |