
Fuel Valve

The three-way fuel valve is used to control the flow of fuel from the fuel tank to the carburetor.



ON: normal position for riding.

OFF: for parking, storing, or transportation. **RES:** for extra fuel to get to a gas station for refueling.

22