

HANDLEBAR SWITCHES

Disconnect the handlebar switch connectors.

Check for continuity between the wire terminals of the handlebar switch connector.

Continuity should exist between the color coded wire terminals as follows:

ENGINE STOP SWITCH

	IG	BAT2
OFF		
RUN	○	○
COLOR	BI	W/BI

STARTER SWITCH

	ST	IG	BAT3	HL
FREE			○	○
PUSH	○	○		
COLOR	Y/R	BI	BI/Br	Bu/W

DIMMER SWITCH

	HL	Lo	HI
Lo			
(N)	○		○
Hi	○		○
COLOR	Bu/W	W	Bu

HORN SWITCH

	Ho	BAT3
FREE		
PUSH	○	○
COLOR	Lg	BI/Br

TURN SIGNAL SWITCH

	W	R	L	BAT5	PR	PL
R	○	○		○		○
N				○	○	○
L	○		○	○		
COLOR	GR	SB	O	Br/W	SB/W	O/W

