

6. FUEL SYSTEM (Programmed Fuel Injection)

COMPONENT LOCATION.....	6-2	THROTTLE BODY	6-72
SERVICE INFORMATION	6-3	PRIMARY INJECTOR.....	6-79
TROUBLESHOOTING	6-5	FAST IDLE WAX UNIT	6-81
SYSTEM LOCATION.....	6-6	STARTER VALVE.....	6-82
SYSTEM DIAGRAM.....	6-7	STARTER VALVE SYNCHRONIZATION	6-86
PGM-FI SELF-DIAGNOSIS INFORMATION	6-8	MAP SENSOR.....	6-88
MIL CODE INDEX.....	6-12	IAT SENSOR	6-89
MIL TROUBLESHOOTING.....	6-15	ECT SENSOR	6-89
DTC CODE INDEX.....	6-33	CAM PULSE GENERATOR.....	6-90
DTC TROUBLESHOOTING.....	6-37	TP SENSOR.....	6-91
FUEL LINE INSPECTION	6-56	BANK ANGLE SENSOR	6-93
FUEL PUMP UNIT.....	6-58	ENGINE STOP RELAY	6-94
FUEL CUT-OFF RELAY	6-60	ENGINE CONTROL MODULE (ECM).....	6-94
FUEL TANK	6-61	PAIR CONTROL SOLENOID VALVE.....	6-96
AIR CLEANER HOUSING	6-64	EVAP PURGE CONTROL SOLENOID VALVE (California type only)	6-98
SECONDARY INJECTOR.....	6-67	O ₂ SENSOR (California type only)	6-99