
clutch lever
front brake fluid reservoir
front brake lever
throttle grip
fuel fill cap
radiator cap


front suspension compression damping adjuster (both left and right)
• rear suspension high speed compression damping adjuster
• rear suspension low speed compression damping adjuster
fast idle knob (engine idle speed)
engine oil filter
crankcase breather tube
engine oil fill cap
rear suspension rebound damping adjuster
front brake caliper
drive chain


rear suspension spring pre-load adjuster
air cleaner
battery
crankcase breather tube
spark plug
engine oil drain bolt
rear brake caliper
rear brake fluid reservoir
rear brake pedal
front suspension rebound damping adjuster (both left and right)