Owner's Manual Storage


Your ATV provides storage for the owner's manual so you'll have it with you for easy reference. Store your owner's manual (1) in the plastic document bag underside of the seat (2).

The owner's manual and spare fuse (3) should be stored in the plastic document bag (4).

To remove the seat, see page 94.

Be careful not to flood this area when washing your ATV or riding through water.

SEAT UNDERSIDE



- (1) owner's manual
- (2) seat

- (3) spare fuse
- (4) plastic document bag