

---

## Load Limits

Following are the load limits for your motorcycle:

**Maximum weight capacity:** = 146 kg (322 lbs)  
includes the weight of the rider, all  
attachments and all cargo

Putting too much weight in individual storage compartments can also affect stability and handling. So be sure to stay within the limits given below:

**Maximum compartment weight:** = 23.6 kg (52.2 lbs)  
includes following maximum  
compartment weights:

<b>rear cowl (radio only, no storage)</b>	= 6.0 kg (13.2 lbs)
<b>each saddlebag</b>	= 6.8 kg (15.0 lbs)
<b>each fairing pocket</b>	= 2.0 kg (4.5 lbs)

## Loading Guidelines

Improperly loading this motorcycle can affect its stability and handling. Even if the motorcycle is properly loaded, you should ride at reduced speeds when carrying cargo.

Follow these guidelines whenever you ride with cargo:

- Check that both tyres are properly inflated (page 41).
- If you change your normal load, you may need to adjust your rear suspension settings (page 28 ) and your headlight (page 61 ).
- To prevent loose items from creating a hazard, make sure that storage lids are properly closed and that any other cargo is securely tied down before you ride away.