

Riding Tips

Check the side stand is retracted before riding and selecting a gear.

Use the gears within the speed ranges given in the table.

To save fuel and prolong the life of the motorcycle, avoid rapid acceleration or deceleration.

Running In

Keep the engine in relatively lower rpm and avoid rapid acceleration and deceleration for the first 500km. This will prolong the life of the engine.



Advice

If you notice any unusual sound or other problems, contact an authorised HONDA dealer as soon as possible.



Tip

- Accelerate as gently as possible.
- Always observe the speed limit.

| Gear | Speed Range |
|-------------|--------------------|
| 1st | 0-50 km/h |
| 2nd | 20-80 km/h |
| 3rd | 25-110 km/h |
| 4th | 30-140 km/h |
| 5th | 40 km/h and above |