


Front Suspension Adjustments

15. Cover the fork piston rod end with soft jaws to prevent fork damage.
Blow the extra oil off to the fork damper (1) spring chamber (9) by pumping the fork damper piston rod to full stroke.

NOTICE

Be careful not to bend or damage the fork damper piston rod when the piston rod is stroked.




(1) fork damper

(9) spring chamber

16. Drain the extra oil from the fork damper (1).

By doing this procedure, about 17 cm³ (0.6 US oz, 0.6 Imp oz) of fork fluid will be drained from the damper spring chamber through the oil hole and cause 175 cm³ (5.9 US oz) of fork fluid to be left in the chamber.



(1) fork damper

17. Blow out the oil from the fork damper spring chamber using compressed air to the oil hole.
Wipe the oil completely off the fork damper.
18. If you can not use compressed air, remove the pressure release screw (10) on the fork cap.
Hold the fork damper upside down for 10 minutes and drain the oil from the fork damper spring chamber.



(10) pressure release screw