
With the ATV in an upright position, check the fluid level. It should be above the LOWER level mark (1). If the level is at or below the LOWER level mark, check the brake pads for wear (page 133).

Worn brake pads should be replaced. If the pads are not worn, have your brake system inspected for leaks.

Rear Brake Fluid Level

RIGHT SIDE



With the ATV in an upright position, check the fluid level. It should be between the UPPER (3) and LOWER (4) level mark. If the level is at or below the LOWER level mark, check the brake pads for wear (page 133).

Worn brake pads should be replaced. If the pads are not worn, have your brake system inspected for leaks.