If You Have a Flat Tire

- Tighten the rear brake bracket bolt to the specified torque:
 51 lbf·ft (69 N·m , 7.0 kgf·m)
- 6. Install the rear axle nut and washer.
- 7. Tighten the rear axle nut to the specified torque:
 94 lbf.ft (127 N·m , 13.0 kgf.m)
- 8. Install the axle holding bolt and washer.
- Tighten the axle holding bolt to the specified torque:
 20 lbf·ft (27 N·m , 2.8 kgf·m)
- 10. After installing the wheel, apply the brake several times. Check for free wheel rotation after the brake is released. Recheck the wheel if the brake drags or the wheel does not rotate freely.

- 11. Install the muffler, muffler bracket bolt A, B, nuts and washers.
 - Before installing the muffler, replace the muffler gasket with a new gasket. Tighten the nuts and bolts to the specified torques: exhaust pipe joint nuts:
 17 lbf·ft (23 N·m , 2.3 kgf·m) muffler bracket bolt A, B and nuts:
 20 lbf·ft (27 N·m , 2.8 kgf·m)

If a torque wrench is not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capability.