

---

## Load Limits

Following are the load limits for your motorcycle:

### Maximum weight capacity:

Includes the weight of the rider, passenger, all cargo and all accessories = 196 kg (432 lbs)

Putting too much weight in individual storage compartments can also affect stability and handling. So be sure to stay within the limits given below:

### Maximum weight:

rear carrier	= 9.0 kg (20.0 lbs)
each saddlebag	= 9.0 kg (20.0 lbs)
each fairing pocket	= 2.0 kg (4.5 lbs)
of all cargo	= 31 kg (68 lbs)

## Loading Guidelines

Improperly loading your motorcycle can affect its stability and handling. Even if your motorcycle is properly loaded, you should ride at reduced speeds and never exceed 130 km/h (80 mph) when carrying cargo.

Follow these guidelines whenever you carry a passenger or cargo:

- Check that both tyres are inflated properly.
- If you change your normal load, you may need to adjust your rear suspension settings (page 28 ) and your headlight (page 66 ).
- To prevent loose items from creating a hazard, make sure that storage lids are properly closed and that any other cargo is securely tied down before you ride away.