


PREPARATION FOR RIDING


[Only for ST70-I and Australia type]

Perform the following tasks before riding.

1. Join the front fork to the body frame. Turn the stem nut ① all the way in counterclockwise and then back off approximately 1/4 turn.
2. Insert the head pipe bolt pin ② into the front fork groove ③, and then firmly tighten the head pipe knob.
3. Loosen the handle bar knob, unfold the handle bar to the normal riding position, insert the stopper located at the base of the handle bar into the handle bar holder groove, and then securely tighten the knob.



① Stem nut



② Head pipe bolt pin ③ Groove