

## Reverse Riding

For reverse riding practice, make sure there are no obstacles or people in the area.

1. Make sure the transmission is in neutral and set the parking brake. Make sure the subtransmission is in H or L.
2. Start the engine.
3. Move the posi-torque speed range and reverse selector lever to the reverse position (page 15).
4. While the engine is idling, depress the gearshift pedal into reverse gear.
5. Ride the TRX cautiously in reverse by gradually opening the throttle.

### NOTE:

- \* The posi-torque speed range and reverse selector lever cannot be moved in the reverse position without the transmission in neutral.

### WARNING

- \* *When backing up, open the throttle carefully to ride slowly and safely, being careful that there are no obstacles or people behind you.*
- \* *Avoid sudden application of the throttle or abrupt turns.*
- \* *Close the throttle and apply both front and rear brakes carefully to stop the TRX when riding in reverse. Applying the rear brake alone may cause the front wheels to lift off the ground.*