

FRONT AND REAR SUSPENSION

Each shock absorber (1) has five adjustment positions for different rider weights and riding conditions.

Position I is for light weight and smooth ground conditions. Positions II to V progressively increase spring tension for a stiffer suspension. Be certain to adjust each shock absorber to the same position.

STANDARD POSITION: II




Fig. 2-18

(1) Shock absorber
(2) Adjuster