

If You Have a Flat Tire

Installation

1. Position the rear wheel and install the rear wheel nuts.
 - Avoid getting grease, oil, or dirt on the disc or pad surfaces. Any contamination can cause poor brake performance or rapid pad wear after reassembly.
2. Tighten the rear wheel nuts to the specified torque:
80 lbf·ft (108 N·m , 11 kgf·m)
3. After installing the wheel, apply the brake several times and then check if the wheel rotates freely. Recheck the wheel if the brake drags or if the wheel does not rotate freely.

4. Install the muffler, muffler mount bolt A, B and nut.
 - Before installing the muffler, replace the muffler gasket with a new gasket. Tighten the bolts to the specified torque:
muffler mount bolt A
16 lbf·ft (22 N·m , 2.2 kgf·m)
muffler mount bolt B and nut
16 lbf·ft (22 N·m , 2.2 kgf·m)
muffler band bolt
16 lbf·ft (22 N·m , 2.2 kgf·m)

If a torque wrench is not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capability.