

# Starting & Stopping the Engine

---

2. With the throttle closed, press the start button (2).
  - Pressing the electric start button for more than 5 seconds at a time may cause the starter to overheat and damage the starter. Release the start button for approximately 10 seconds before pressing it again.
3. Immediately after the engine starts, operate the choke knob to keep fast idle.
4. About a half minute after the engine starts, push the choke knob right all the way to fully OFF (B).
5. If idling is unstable, hold open the throttle slightly, do not blip the throttle.